

5.2.9.42. AliroSupportedBLEUWBProtocolVersions Attribute

This attribute SHALL indicate the list of protocol versions supported for the Bluetooth LE + UWB Access Control Flow as defined in [\[Aliro\]](#).

5.2.9.43. AliroBLEAdvertisingVersion Attribute

This attribute SHALL indicate the version of the Bluetooth LE advertisement as defined in [\[Aliro\]](#).

5.2.9.44. NumberOfAliroCredentialIssuerKeysSupported

This attribute SHALL indicate the maximum number of [AliroCredentialIssuerKey](#) credentials that can be stored on the lock.

5.2.9.45. NumberOfAliroEndpointKeysSupported

This attribute SHALL indicate the maximum number of endpoint key credentials that can be stored on the lock. This limit applies to the sum of the number of [AliroEvictableEndpointKey](#) credentials and the number of [AliroNonEvictableEndpointKey](#) credentials.

NOTE

The credential indices used for these two credential types are independent of each other, similar to all other credential types. As long as NumberOfAliroEndpointKeysSupported is at least 2 a client could add a credential of type AliroEvictableEndpointKey at any index from 1 to NumberOfAliroEndpointKeysSupported and also add a credential of type AliroNonEvictableEndpointKey at the same index, and both credentials would exist on the server.

5.2.10. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	LockDoor	client ⇒ server	Y	O T	M
0x01	UnlockDoor	client ⇒ server	Y	O T	M
0x02	Toggle	client ⇒ server	Y	O T	X
0x03	UnlockWith-Timeout	client ⇒ server	Y	O T	O
0x05	SetPINCode	client ⇒ server	Y	A T	!USR & PIN
0x06	GetPINCode	client ⇒ server	GetPINCodeResponse	A	!USR & PIN
0x06	GetPIN-CodeResponse	client ⇐ server	N		!USR & PIN
0x07	ClearPINCode	client ⇒ server	Y	A T	!USR & PIN
0x08	ClearAllPIN-Codes	client ⇒ server	Y	A T	!USR & PIN
0x09	SetUserStatus	client ⇒ server	Y	A	!USR & (PIN RID FGP)