

5.2.10.3.1. Timeout Field

This field SHALL indicate the timeout in seconds to wait before relocking the door lock. This value is independent of the AutoRelockTime attribute value.

5.2.10.3.2. PINCode Field

See [Section 5.2.10.1.1, “PINCode Field”](#).

5.2.10.4. SetPINCode Command

Set a PIN Code into the lock.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M
1	UserStatus	UserStatusEnum	desc	X		M
2	UserType	UserTypeEnum	all	X		M
3	PIN	octstr				M

Return status is a global status code or a cluster-specific status code from the [Status Codes](#) table and SHALL be one of the following values:

Name	Summary
SUCCESS	Setting PIN code was successful.
FAILURE	Setting PIN code failed.
CONSTRAINT_ERROR	Setting PIN code failed because User ID requested was out of range.
DUPLICATE	Setting PIN code failed because it would create a duplicate PIN code.

5.2.10.4.1. UserID Field

This field SHALL indicate the user ID. The value of the UserID field SHALL be between 0 and the value of the NumberOfPINUsersSupported attribute.

5.2.10.4.2. UserStatus Field

This field SHALL indicate the user status. Only the values 1 (Occupied/Enabled) and 3 (Occupied/Disabled) are allowed for UserStatus.

5.2.10.5. GetPINCode Command

Retrieve a PIN Code.