

user status has to be set to "0 Available", the user type has to be set to the default value, and all schedules which are supported have to be set to the default values.

5.2.10.32. SetUser Command

Set user into the lock.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	OperationType	DataOperationTypeEnum	Add, Modify			M
1	UserIndex	uint16	1 to NumberOfTotalUsersSupported			M
2	UserName	string	max 10	X		M
3	UserUnique ID	uint32	all	X		M
4	UserStatus	UserStatusEnum	OccupiedEnabled, OccupiedDisabled	X		M
5	UserType	UserTypeEnum	UnrestrictedUser, NonAccessUser, ForcedUser, DisposableUser, ExpiringUser, ScheduleRestrictedUser, RemoteOnlyUser	X		M
6	CredentialRule	CredentialRuleEnum		X		M

Fields used for different use cases: