

- If the OperationType is Add, the UserStatus in the resulting user record SHALL be set to default value specified above.
- If the OperationType is Modify, the UserStatus in the user record SHALL NOT be changed from the current value.

If UserStatus is not null, the UserStatus in the user record SHALL be set to the provided value.

5.2.10.32.6. UserType Field

This field SHALL indicate the UserType to assign to this user when created or modified.

If UserType is null then:

- If the OperationType is Add, the UserType in the resulting user record SHALL be set to default value specified above.
- If the OperationType is Modify, the UserType in the user record SHALL NOT be changed from the current value.

If UserType is not null, the UserType in the user record SHALL be set to the provided value.

5.2.10.32.7. CredentialRule Field

This field SHALL indicate the CredentialRule to use for this user.

The valid CredentialRule enumeration values depends on the bits in the [CredentialRulesBitmap](#) map. Each bit in the map identifies a valid CredentialRule that can be used.

If CredentialRule is null then:

- If the OperationType is Add, the CredentialRule in the resulting user record SHALL be set to default value specified above.
- If the OperationType is Modify, the CredentialRule in the user record SHALL NOT be changed from the current value.

If CredentialRule is not null, the CredentialRule in the user record SHALL be set to the provided value.

5.2.10.33. GetUser Command

Retrieve user.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserIndex	uint16	1 to NumberOfTotalUsersSupported			M

An InvokeResponse command SHALL be sent with an appropriate error (e.g. FAILURE, INVALID_