

5.2.10.36.5. UserStatus Field

This field SHALL indicate the user status to use in the new user record if a new user is being created. This SHALL be null if OperationType is Modify. This MAY be null when adding a new credential and user.

5.2.10.36.6. UserType Field

This field SHALL indicate the user type to use in the new user record if a new user is being created. This SHALL be null if OperationType is Modify. This MAY be null when adding a new credential and user.

5.2.10.37. SetCredentialResponse Command

Returns the status for setting the specified credential.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	status	desc			M
1	UserIndex	uint16	1 to NumberOfTotalUsersSupported	X		M
2	NextCredentialIndex	uint16	desc	X		O

5.2.10.37.1. Status Field

Status comes from the [Status Codes](#) table and SHALL be one of the following values:

- SUCCESS, if setting user credential was successful.
- FAILURE, if some unexpected internal error occurred setting user credential.
- OCCUPIED, if OperationType is Add and CredentialIndex in Credential structure points to an occupied slot.
- OCCUPIED, if OperationType is Modify and CredentialIndex in Credential structure does not match the CredentialIndex that is already associated with the provided UserIndex.
- DUPLICATE, if CredentialData provided is a duplicate of another credential with the same CredentialType (e.g. duplicate PIN code).
- RESOURCE_EXHAUSTED, if OperationType is Add and the new credential cannot be added due to resource constraints such as:
 - The user referred to by UserIndex already has NumberOfCredentialsSupportedPerUser credentials associated.
 - The credential is of type [AliroEvictableEndpointKey](#) or [AliroNonEvictableEndpointKey](#), and adding it would cause the total number of credentials of those two types to exceed [NumberOfAliroEndpointKeysSupported](#).