

5.4.8.3. Calibrate Command

This command is used to trigger a calibration of the closure.

5.4.8.3.1. Effect on Receipt

Upon receipt, this SHALL initiate a calibration of the closure.

Procedures of how to achieve the calibration are manufacturer-specific.

If this command is received when already in the *Calibrating* state, the server SHALL respond with a status code of SUCCESS. Else, if this command is invoked in any state other than *Stopped* or *SetupRequired*, the server SHALL respond with INVALID_IN_STATE and there SHALL be no other effect.

Otherwise:

- The MainState attribute SHALL be set to *Calibrating*.
- The server SHALL respond with a status code equal to SUCCESS.

5.4.9. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	OperationalError	CRITICAL		V	M
0x01	MovementCompleted	INFO		V	!IS
0x02	EngageStateChanged	INFO		V	MO
0x03	SecureStateChanged	INFO		V	M

5.4.9.1. OperationalError Event

This event SHALL be generated when a reportable error condition is detected. A closure that generates this event SHALL also set the MainState attribute to Error, indicating an error condition.

This event SHALL contain the following fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ErrorState	list[ClosureErrorEnum]	1 to 10[all]			M

5.4.9.2. MovementCompleted Event

This event, if supported, SHALL be generated when the overall operation ends, either successfully or otherwise. For example, the event is sent upon the completion of a movement operation in a