

5.5.6.4. ModulationTypeEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	SlatsOrientation	Orientation of the slats	M
1	SlatsOpenwork	Aperture of the slats	M
2	StripesAlignment	Alignment of blind stripes (Zebra)	M
3	Opacity	Opacity of a surface	M
4	Ventilation	Ventilation control	M

5.5.6.5. ClosureUnitEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Millimeter	Millimeter used as unit	M
1	Degree	Degree used as unit	M

5.5.6.6. StepDirectionEnum Type

This data type is derived from enum8 and used for the Step command to indicate the direction of the steps.

Value	Name	Summary	Conformance
0	Decrease	Decrease towards 0.00%	M
1	Increase	Increase towards 100.00%	M

5.5.6.7. RangePercent100thsStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Min	per-cent100ths	all				M
1	Max	per-cent100ths	Min to 100.00%				M

5.5.6.8. UnitRangeStruct Type