

5.5.6.10.1. RemoteLatching Bit

This bit SHALL indicate whether the latch supports remote latching or not:

- 0 = the latch can only be latched through manual, physical operation.
- 1 = the latch can be latched via remote control (e.g., electronic or remote actuation).

5.5.6.10.2. RemoteUnlatching Bit

This bit SHALL indicate whether the latch supports remote unlatching or not:

- 0 = the latch can only be unlatched through manual, physical operation.
- 1 = the latch can be unlatched via remote control (e.g., electronic or remote actuation).

5.5.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	CurrentState	DimensionStateStruct	desc	Q X	null	R V	M
0x0001	TargetState	DimensionStateStruct	desc	X	null	R V	M
0x0002	Resolution	percent100ths	min 0.01%	F	0.01%	R V	PS
0x0003	StepValue	percent100ths	min 0.01%	F	0.01%	R V	PS
0x0004	Unit	ClosureUnitEnum	all	F		R V	UT
0x0005	UnitRange	UnitRangeStruct	desc	X	null	R V	UT
0x0006	LimitRange	RangePercent100thsStruct	desc			R V	LM
0x0007	TranslationDirection	TranslationDirectionEnum	all	F		R V	TR
0x0008	RotationAxis	RotationAxisEnum	all	F		R V	RO
0x0009	Overflow	OverflowEnum	all	F		R V	RO