

Cluster ID	Cluster Name	Description
0x050A	Content Launcher	This cluster provides an interface for launching content on a Video Player device or a Content App.
0x0509	Keypad Input	This cluster provides an interface for controlling a Video Player or a Content App using action commands such as UP, DOWN, and SELECT.
0x0507	Media Input	This cluster provides an interface for controlling the Input Selector on a Video Player device.
0x0506	Media Playback	This cluster provides an interface for controlling Media Playback (PLAY, PAUSE, etc) on a Video Player device.
0x0505	Target Navigator	This cluster provides an interface for UX navigation within a set of targets on a Video Player device or Content App endpoint.
0x050F	Content Control	This cluster provides an interface for controlling Content controls such as turning on/off Content Control feature on a Video Player device.

Example Usage of the Media Clusters