

and continue. For example, if the current channel is at index 0 and count value of -1 is given, then the current channel should change to the last channel.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Count	int16	all			M

6.6.7.4.1. Count Field

This field SHALL indicate the number of steps to increase (Count is positive) or decrease (Count is negative) the current channel.

6.6.7.5. GetProgramGuide Command

This command retrieves the program guide. It accepts several filter parameters to return specific schedule and program information from a content app. The command shall receive in response a ProgramGuideResponse. Standard error codes SHALL be used when arguments provided are not valid. For example, if StartTime is greater than EndTime, the status code INVALID_ACTION SHALL be returned.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StartTime	epoch-s				M
1	EndTime	epoch-s				M
2	ChannelList	list[ChannelInfoStruct]	max 255		empty	O
3	PageToken	PageTokenStruct		X	null	O
5	RecordingFlag	RecordingFlagBitmap		X	null	O
6	ExternalIDList	list[AdditionalInfoStruct]	max 255		empty	O
7	Data	octstr	max 8092		MS	O

6.6.7.5.1. StartTime Field

This field SHALL indicate the beginning of the time window for which program guide entries are to be retrieved, as a UTC time. Entries with a start time on or after this value will be included in the results.

6.6.7.5.2. EndTime Field

This field SHALL indicate the end of the time window for which program guide entries are to be retrieved, as a UTC time. Entries with an end time on or before this value will be included in the