

ID	Name	Direction	Response	Access	Conformance
0x0D	AddBlockApplications	client ⇒ server	Y	M	BA
0x0E	RemoveBlockApplications	client ⇒ server	Y	M	BA
0x0F	SetBlockContentTimeWindow	client ⇒ server	Y	M	BTW
0x10	RemoveBlockContent-TimeWindow	client ⇒ server	Y	M	BTW

6.13.8.1. UpdatePIN Command

The purpose of this command is to update the PIN used for protecting configuration of the content control settings. Upon success, the old PIN SHALL no longer work.

The PIN is used to ensure that only the Node (or User) with the PIN code can make changes to the Content Control settings, for example, turn off Content Controls or modify the ScreenDailyTime. The PIN is composed of a numeric string of up to 6 human readable characters (displayable) .

Upon receipt of this command, the media device SHALL check if the OldPIN field of this command is the same as the current PIN. If the PINs are the same, then the PIN code SHALL be set to NewPIN. Otherwise a response with InvalidPINCode error status SHALL be returned.

The media device MAY provide a default PIN to the User via an out of band mechanism. For security reasons, it is recommended that a client encourage the user to update the PIN from its default value when performing configuration of the Content Control settings exposed by this cluster. The ResetPIN command can also be used to obtain the default PIN.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	OldPIN	string	max 6			M
1	NewPIN	string	max 6			M

6.13.8.1.1. OldPIN Field

This field SHALL specify the original PIN. Once the UpdatePIN command is performed successfully, it SHALL be invalid.

6.13.8.1.2. NewPIN Field

This field SHALL indicate a new PIN for the Content Control feature.

6.13.8.2. ResetPIN Command

The purpose of this command is to reset the PIN.