

| Revision | Description                                                                                                                                                                                                                                   |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2        | Add constraint about switching from non-Idle to non-Idle modes. ChangeToModeResponse command: StatusText must be provided for InvalidInMode status. Deprecate the OnMode attribute and the related feature map bit. Add the Mapping mode tag. |
| 3        | Remove constraint on changing cleaning modes while the RVC Run Mode cluster is in a non-Idle mode. Continue to allow InvalidInMode response for devices that do not support such mode changes.                                                |
| 4        | DirectModeChange made non-provisional                                                                                                                                                                                                         |

### 7.2.2. Classification

| Hierarchy | Role        | Scope    | PICS Code |
|-----------|-------------|----------|-----------|
| Mode Base | Application | Endpoint | RVCRUNM   |

### 7.2.3. Cluster ID

| ID     | Name         |
|--------|--------------|
| 0x0054 | RVC Run Mode |

### 7.2.4. Features

This cluster SHALL support the FeatureMap bitmap attribute as defined below.

| Bit | Code         | Feature          | Conformance | Summary                                                  |
|-----|--------------|------------------|-------------|----------------------------------------------------------|
| 0   | DEPONOFF     | OnOff            | X           | Dependency with the OnOff cluster                        |
| 20  | DIRECTMODECH | DirectModeChange | O           | Cluster supports changing run modes from non-Idle states |

#### 7.2.4.1. DirectModeChange Feature

This feature indicates whether the cluster implementation supports changing the run modes while the RVC Run Mode cluster's CurrentMode attribute is set to a mode without the Idle mode tag. If the implementation does not support such a change, the ChangeToModeResponse command SHALL have the StatusCode field set to the InvalidInMode value.