

For the "Turbo, Vacuum Only" mode, tags: 0x4000 (Deep Clean), 0x4001 (Vacuum).

For the "Mop Only" mode, tags: 0x4002 (Mop), 0x0003 (Low Noise).

For the "Rapid Vacuum and Mop" mode, tags: 0x0001 (Quick), 0x4001 (Vacuum), 0x4002 (Mop).

Note that the "Low Noise" and "Quick" mode tags are defined in the generic Mode Base cluster specification.

7.4. RVC Operational State Cluster

This cluster is derived from the Operational State cluster and provides an interface for monitoring the operational state of a robotic vacuum cleaner.

7.4.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	The Pause and Resume commands are usable in all compatible states. Deprecate the Start and Stop commands. Add the GoHome command.
3	Add several operational states and errors

7.4.2. Classification

Hierarchy	Role	Scope	PICS Code
Operational State	Application	Endpoint	RVCOPSTATE

7.4.3. Cluster ID

ID	Name
0x0061	RVC Operational State

7.4.4. Data Types

7.4.4.1. OperationalStateEnum Type

This data type is derived from enum8.

The values defined herein are applicable to this derived cluster of Operational State only and are additional to the set of values defined in Operational State itself.