

Value	Name	Summary	Conformance
0x00	Stopped	The device is stopped	M
0x01	Running	The device is operating	M
0x02	Paused	The device is paused during an operation	M
0x03	Error	The device is in an error state	M
0x40	SeekingCharger	The device is en route to the charging dock	M
0x41	Charging	The device is charging	M
0x42	Docked	The device is on the dock, not charging	M
0x43	EmptyingDustBin	The device is automatically emptying its own dust bin, such as to a dock	O
0x44	CleaningMop	The device is automatically cleaning its own mopping device, such as on a dock	O
0x45	FillingWaterTank	The device is automatically filling its own clean water tank for use when mopping, such as from a dock	O
0x46	UpdatingMaps	The device is processing acquired data to update its maps	O

RVC Pause Compatibility defines the compatibility of the states this cluster defines with the Pause command.

Table 13. RVC Pause Compatibility

State Value	State Name	Pause-Compatible	Notes
0x40	SeekingCharger	Y	
0x41	Charging	N	
0x42	Docked	N	
0x43	EmptyingDustBin	N	
0x44	CleaningMop	N	
0x45	FillingWaterTank	N	