

State Value	State Name	Pause-Compatible	Notes
0x46	UpdatingMaps	N	

RVC Resume Compatibility defines the compatibility of the states this cluster defines with the Resume command.

Table 14. RVC Resume Compatibility

State Value	State Name	Resume-Compatible	Notes
0x40	SeekingCharger	N	
0x41	Charging	Y	
0x42	Docked	Y	
0x43	EmptyingDustBin	N	
0x44	CleaningMop	N	
0x45	FillingWaterTank	N	
0x46	UpdatingMaps	N	

While in the Charging or Docked states, the device SHALL NOT attempt to resume unless it transitioned to those states while operating and can resume, such as, for example, if it is recharging while in a cleaning cycle. Else, if the operational state is Charging or Docked but there's no operation to resume or the operation can't be resumed, the device SHALL respond with an **OperationalCommandResponse** command with an ErrorStateID of CommandInvalidInState but take no further action.

7.4.4.2. ErrorStateEnum Type

This data type is derived from enum8.

The values defined herein are applicable to this derived cluster of Operational State only and are additional to the set of values defined in Operational State itself.

Value	Name	Summary	Conformance
0x00	NoError	The device is not in an error state	M
0x01	UnableToStartOrResume	The device is unable to start or resume operation	M
0x02	UnableToCompleteOperation	The device was unable to complete the current operation	M
0x03	CommandInvalidInState	The device cannot process the command in its current state	M