

A device that receives this command in any state which does not allow seeking the charger, such as Charging or Docked, SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of CommandInvalidInState and SHALL have no other effect.

Otherwise, on success:

- The OperationalState attribute SHALL be set to SeekingCharger.
- The device SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of NoError.
- After the device reaches the dock and completes its docking activities, the RVC Run Mode cluster's CurrentMode attribute SHALL be set to an Idle mode.