

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	MaxTemperature	temperature	desc	F		R V	TN
0x0003	Step	temperature	1 to (MaxTemperature - MinTemperature)	F		R V	STEP
0x0004	Select-edTemperatureLevel	uint8	max 31			R V	TL
0x0005	SupportedTemperatureLevels	list[string]	max 32[max 16]			R V	TL

NOTE

See the **temperature** data type, in the data model, for encoding units. The scalar values are uint16 counts of 0.01C. For example, MinTemperature of -1800 is -18.00C.

8.2.5.1. TemperatureSetpoint Attribute

This attribute SHALL represent the desired Temperature Setpoint on the device.

8.2.5.2. MinTemperature Attribute

This attribute SHALL represent the minimum temperature to which the TemperatureSetpoint attribute MAY be set.

8.2.5.3. MaxTemperature Attribute

This attribute SHALL represent the maximum temperature to which the TemperatureSetpoint attribute MAY be set.

If the Step attribute is supported, this attribute SHALL be such that $\text{MaxTemperature} = \text{MinTemperature} + (\text{Step} * n)$, where n is an integer and $n > 0$. If the Step attribute is not supported, this attribute SHALL be such that $\text{MaxTemperature} > \text{MinTemperature}$.

8.2.5.4. Step Attribute

This attribute SHALL represent the discrete value by which the TemperatureSetpoint attribute can be changed via the SetTemperature command.

For example, if the value of MinTemperature is 25.00C (2500) and the Step value is 0.50C (50), valid values of the TargetTemperature field of the SetTemperature command would be 25.50C