

sent as the response. If null is written to this attribute, there will be no spin speed for the selected cycle. If the value is null, there will be no spin speed on the current mode.

8.6.6.3. NumberOfRinses Attribute

This attribute SHALL indicate how many times a rinse cycle SHALL be performed on a device for the current mode of operation. A value of None SHALL indicate that no rinse cycle will be performed. This value may be set by the client to adjust the number of rinses that are performed for the current mode of operation. If the device is not in a compatible state to accept the provided value, an INVALID_IN_STATE error SHALL be sent as the response.

8.6.6.4. SupportedRinses Attribute

This attribute SHALL indicate the amount of rinses allowed for a specific mode. Each entry SHALL indicate a NumberOfRinsesEnum value that is possible in the selected mode on the device. The value of this attribute MAY change at runtime based on the currently selected mode. Each entry SHALL be distinct.

8.7. Refrigerator And Temperature Controlled Cabinet Mode Cluster

This cluster is derived from the Mode Base cluster and defines additional mode tags and name-spaced enumerated values for refrigerator and temperature controlled cabinet devices.

8.7.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	ChangeToModeResponse command: StatusText must be provided for InvalidInMode status
3	Set OnOff feature, StartUpMode, and OnMode as disallowed (previously a Device Type override)

8.7.2. Classification

Hierarchy	Role	Scope	PICS Code
Mode Base	Application	Endpoint	TCCM

8.7.3. Cluster ID