

9.2.7.15. SlotAdjustmentStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	SlotIndex	uint8	desc				M
1	NominalPower	power-mW	desc				PFR
2	Duration	elapsed-s	desc				M

9.2.7.15.1. SlotIndex Field

This field SHALL indicate the index into the Slots list within the [Forecast](#) that is to be modified. It SHALL be less than the actual length of the Slots list (implicitly it must be in the range 0 to 9 based on the maximum length of the Slots list constraint).

9.2.7.15.2. NominalPower Field

This field SHALL indicate the new requested power that the ESA SHALL operate at. It SHALL be between the [AbsMinPower](#) and [AbsMaxPower](#) attributes as advertised by the ESA if it supports **PFR**.

This is a signed value and can be used to indicate charging or discharging.

If the ESA does NOT support **PFR** this value SHALL be ignored by the ESA.

9.2.7.15.3. Duration Field

This field SHALL indicate the new requested duration, in seconds, that the ESA SHALL extend or shorten the slot duration to. It SHALL be between the [MinDurationAdjustment](#) and [MaxDurationAdjustment](#) for the slot as advertised by the ESA.

9.2.7.16. ConstraintsStruct Type

The ConstraintsStruct allows a client to inform an ESA about a constraint period (such as a grid event, or perhaps excess solar PV). The format allows the client to suggest that the ESA can either turn up its energy consumption, or turn down its energy consumption during this period.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	StartTime	epoch-s	desc				M
1	Duration	elapsed-s	max 86400				M
2	NominalPower	power-mW	desc				PFR
3	MaximumEnergy	energy-mWh	all				PFR
4	LoadControl	int8	all				SFR