

GRID meter = Σ LoadPowers + Σ GeneratorPowers

Example:

Home has the following loads:		
	Water Heater:	3000W
	TV:	200W
	FridgeFreezer:	200W
	Total:	3400W

Home has the following generators (ESACanGenerate = true)		
	Solar:	-2500W
	BESS:	-900W
	Total:	-3400W

GRID Meter:		
	Σ Loads:	3400W
	Σ Generators:	-3400W
	Total:	0W

9.2.8.3. ESASState Attribute

This attribute SHALL indicate the current state of the ESA.

If the ESA is in the Offline or Fault state it cannot be controlled by an EMS, and may not be able to report its Forecast information. An EMS may subscribe to the [ESASState](#) to get notified about changes in operational state.

The ESA may have a local user interface to allow a service technician to put the ESA into Offline mode, for example to avoid the EMS accidentally starting or stopping the appliance when it is being serviced or tested.

9.2.8.4. AbsMinPower Attribute

This attribute SHALL indicate the minimum electrical power that the ESA can consume when switched on. This does not include when in power save or standby modes.

NOTE

For Generator ESAs that can discharge an internal battery (such as a battery storage inverter) to loads in the home, the [AbsMinPower](#) will be a negative number representing the maximum power that the ESA can discharge its internal battery.