

ID	Name	Direction	Response	Access	Conformance
0x06	RequestConstraintBased-Forecast	client ⇒ server	Y	O	CON
0x07	CancelRequest	client ⇒ server	Y	O	STA FA CON

9.2.9.1. PowerAdjustRequest Command

Allows a client to request an adjustment in the power consumption of an ESA for a specified duration.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Power	power-mW	desc			M
1	Duration	elapsed-s	desc			M
2	Cause	Adjustment-CauseEnum	desc			M

9.2.9.1.1. Power Field

This field SHALL indicate the power that the ESA SHALL use during the adjustment period.

This value SHALL be between the MinPower and MaxPower fields of the [PowerAdjustStruct](#) in the PowerAdjustmentCapability attribute.

9.2.9.1.2. Duration Field

This field SHALL indicate the duration that the ESA SHALL maintain the requested power for.

This value SHALL be between the MinDuration and MaxDuration fields of the [PowerAdjustStruct](#) in the PowerAdjustmentCapability attribute.

9.2.9.1.3. Cause Field

This field SHALL indicate the cause of the request from the EMS.

9.2.9.1.4. Effect on receipt

On receipt of this command, the ESA SHALL validate that the Power and Duration specified in the command are within the limits of its current operation and advertised [PowerAdjustmentCapability](#) attribute, the [OptOutState](#) permits the specified [AdjustmentCauseEnum](#) (see [OptOutState](#) for details), and the [ESAState](#) is Online.

If the PowerAdjustRequest command is accepted, then the ESA SHALL change its [ESAState](#) to PowerAdjustActive, and the [PowerAdjustmentCapability](#) attribute SHALL be updated to set the Cause value from the Cause field of this command.

The command status returned SHALL be SUCCESS if the adjustment is accepted; otherwise the com-