

Paused State Whilst in the Paused state, the ESA SHALL NOT consume or produce significant power (other than required to keep its basic control system operational).

Pause timer expiry When the Pause timer expires the ESA SHALL automatically resume operation. When it does this, then it SHALL also generate a [Resumed](#) Event and the [ESAState](#) SHALL be updated accordingly to reflect its current state (for example, it may still have [PowerAdjustActive](#) now it has resumed from the Pause). The ESA SHALL update its [Forecast](#) including setting [ForecastUpdateReason](#) to [InternalOptimization](#) to account for the resumption after the pause.

Receiving a further pause request command whilst paused If a further Pause Request is received in the same forecast slot whilst already in the paused state, the ESA SHALL again validate that the Duration value is within the range of the (possibly revised) [MinPauseDuration](#) and [MaxPauseDuration](#). If it is outside of this range then the command SHALL be rejected with [CONSTRAINT_ERROR](#).

If the command is accepted the pause timer SHALL be extended by the new Duration.

ResumeRequest A client MAY send a ResumeRequest command, before the Pause timer has expired, to request the ESA to return to its normal operating state. See [ResumeRequest](#) for details.

Failure or Opt-out during PauseRequest A consumer MAY decide to opt-out of the remotely commanded PauseRequest by updating the [OptOutState](#), and the ESA SHALL also change the [ESAState](#) to the new state.

If the ESA develops a fault whilst Paused, the [ESAState](#) SHALL be set to Fault.

On change of [ESAState](#) (from Paused to another state), the ESA SHALL generate a [Resumed](#) Event.

9.2.9.5. ResumeRequest Command

Allows a client to cancel the PauseRequest command and enable earlier resumption of operation.

9.2.9.5.1. Effect on receipt

On receipt of this command, if the ESA supports [PAU](#) and it is currently Paused, the ESA MAY decide not to resume immediately if the [MinPauseDuration](#) has not yet elapsed. This behavior is manufacturer specific.

If accepted, the ESA SHALL resume its operation. The ESA SHALL also generate a [Resumed](#) Event and the [ESAState](#) SHALL be updated accordingly to reflect its current state.

The command status returned SHALL be SUCCESS if the operation is resumed, or the command SHALL be rejected with the response [INVALID_IN_STATE](#) if the ESA is not currently Paused, otherwise the command SHALL be rejected with [FAILURE](#).

The ESA SHALL update its [Forecast](#) including setting [ForecastUpdateReason](#) to [InternalOptimization](#) to account for the resumption after the pause.

9.2.9.6. ModifyForecastRequest Command

Allows a client to modify a Forecast within the limits allowed by the ESA.