

```
MinimumChargeCurrent <= UserMaximumChargeCurrent <= MaximumChargeCurrent
```

where `MinimumChargeCurrent` and `MaximumChargeCurrent` are the values received in the [EnableCharging](#) command.

Its default value SHOULD be initialized to the same as the [CircuitCapacity](#) attribute. This value SHALL be persisted across reboots to ensure it does not cause charging issues during temporary power failures.

9.3.8.11. RandomizationDelayWindow Attribute

This attribute SHALL indicate the size of a random window over which the EVSE will randomize the start of a charging session. This value is in seconds.

This is a feature that is mandated in some markets (such as UK) where the EVSE should by default randomize its start time within the randomization window. By default in the UK this should be 600s.

For example, if the `RandomizationDelayWindow` is 600s (i.e. 10 minutes) and if there was a cheap rate energy starting at 00:30, then the EVSE must compute a random delay between 0-599s and add this to its initial planned start time.

9.3.8.12. NextChargeStartTime Attribute

This attribute SHALL indicate the time, in UTC, when the EVSE plans to start the next scheduled charge based on the charging preferences.

A null value indicates that there is no scheduled charging (for example, the EVSE Mode is set to use Manual mode tag), or that the vehicle is not plugged in with the `SupplyState` indicating that charging is enabled.

9.3.8.13. NextChargeTargetTime Attribute

This attribute SHALL indicate the time, in UTC, when the EVSE SHOULD complete the next scheduled charge based on the charging preferences.

A null value indicates that there is no scheduled charging (for example, the EVSE Mode is set to use Manual mode tag), or that the vehicle is not plugged in with the `SupplyState` indicating that charging is enabled.

9.3.8.14. NextChargeRequiredEnergy Attribute

This attribute SHALL indicate the amount of energy that the EVSE is going to attempt to add to the vehicle in the next charging target.

A null value indicates that there is no scheduled charging (for example, the EVSE Mode is set to use Manual mode tag), or that the vehicle is not plugged in with the `SupplyState` indicating that charging is enabled, or that the next [ChargingTargetStruct](#) is using the `TargetSoC` value to charge the vehicle.