

Chapter 11. Cameras

The Cluster Library is made of individual chapters such as this one. See Document Control in the Cluster Library for a list of all chapters and documents. References between chapters are made using a *X.Y* notation where *X* is the chapter and *Y* is the sub-section within that chapter.

11.1. General Description

11.1.1. Introduction

The clusters specified in this section are used to set up and control camera devices.

11.1.2. Cluster List

This section lists the clusters specified in this document, and gives examples of typical usage for the purpose of clarification.

Table 18. Clusters Specified in the Camera Functional Domain

Cluster ID	Cluster Name	Description
0x0551	Camera AV Stream Management	Management of Camera AV Streams
0x0552	Camera AV Settings User-Level Management	Management of Camera User-Level AV Settings
0x0553	WebRTC Transport Provider	Camera side of WebRTC
0x0554	WebRTC Transport Requestor	Viewer side of WebRTC
0x0555	Push AV Stream Transport	Setup and use of Push Transport
0x0556	Chime	Selection and playing of pre-installed chime sounds

11.1.3. Data Types

11.1.3.1. StreamUsageEnum Type

This data type is derived from enum8.

This data type provides an enumeration of the different usages of streams supported by the camera. This categorization indicates the use-case of a specific stream and thus factors into its priority in terms of resource allocation by the camera. For example, a Recording stream MAY be given higher priority than a LiveView stream to maintain a higher quality in terms of resolution, bitrate, etc.

Value	Name	Summary	Conformance
0	Internal	Internal video stream.	M