

Value	Name	Summary	Conformance
1	Recording	Stream for recording clips.	O
2	Analysis	Stream for analysis and entity detection.	O
3	LiveView	Stream for liveview.	M

11.1.3.1.1. Internal Value

Stream is used for internal purposes, e.g., robotic vacuum using camera for navigation. While the primary use-case for a stream of this usage-type is for an internal purpose, it MAY be re-used for other camera functions, e.g., LiveView. However, this stream SHALL not be modified.

11.1.3.1.2. Recording Value

Stream is used for clip upload and archival.

11.1.3.1.3. Analysis Value

Stream is used for automated audio/video analysis without archival.

11.1.3.1.4. LiveView Value

Stream is used for live watching through client devices.

11.1.3.2. ViewportStruct Type

This struct is used to encode a bounding rectangle of the viewport on the image sensor

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	X1	uint16	all				M
1	Y1	uint16	all				M
2	X2	uint16	all				M
3	Y2	uint16	all				M

11.1.3.2.1. X1 Field

This field SHALL represent the position of the starting vertex along the horizontal (x) axis.

11.1.3.2.2. Y1 Field

This field SHALL represent the position of the starting vertex along the vertical (y) axis.

11.1.3.2.3. X2 Field

This field SHALL represent the position of the ending vertex along the horizontal (x) axis.