

ID	Name	Direction	Response	Access	Quality	Conformance
0x0C	CaptureSnapshot	client ⇒ server	CaptureSnapshotResponse	O	L	SNP
0x0D	CaptureSnapshotResponse	server ⇒ client	N		L	SNP

11.2.8.1. AudioStreamAllocate Command

This command SHALL allocate an audio stream on the camera and return an allocated audio stream identifier.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0x00	StreamUsage	StreamUsageEnum	Recording, Analysis, LiveView			M
0x01	AudioCodec	AudioCodecEnum	all			M
0x02	ChannelCount	uint8	1 to 8			M
0x03	SampleRate	uint32	min 1			M
0x04	BitRate	uint32	min 1			M
0x05	BitDepth	uint8	8, 16, 24, 32			M

11.2.8.1.1. StreamUsage Field

This field SHALL indicate the usage of the stream (Recording, LiveView, etc) that this allocation is for.

11.2.8.1.2. AudioCodec Field

This field SHALL indicate the type of Codec used by the allocated stream.

11.2.8.1.3. ChannelCount Field

This field SHALL indicate the number of channels used by the allocated stream, e.g., Mono (1), Stereo (2), etc.

11.2.8.1.4. SampleRate Field

This field SHALL indicate the sampling rate of the audio stream in Hz. Typical values would be 48000 (48 kHz), 32000 (32 kHz) or 16000 (16 kHz).