

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x050D	Device Energy Management		Utility	Endpoint

2.7.3. Conditions

See the Base Device Type definition for conformance tags.

Condition	Description
ControllableESA	The DEM cluster on this endpoint accepts commands to adjust its energy operation.

A **ControllableESA** device is one that allows a client to request either a change in power (**PowerAdjustment** feature), a change in the start time (**StartTimeAdjustment** feature), to be paused and resumed (**Pausable** feature), or to have its power or state forecast adjusted (**ForecastAdjustment** or **ConstraintBasedAdjustment** features).

Simple reporting of the Forecast as a single capability on its own (**PowerForecastReporting** or **StateForecastReporting** feature support) does not require the ControllableESA condition.

2.7.4. Cluster Requirements

Each endpoint supporting this device type SHALL include these clusters based on the conformance defined below.

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x0098	Device Energy Management	Server		M
0x009F	Device Energy Management Mode	Server		ControllableESA, O
0x00A0	Electrical Grid Conditions	Client		O

2.7.5. Element Requirements

The table below lists qualities and conformance that override the cluster specification requirements. A blank table cell means there is no change to that item and the value from the cluster specification applies.