

Revision	Description
3	Updated the Scenes cluster to Scenes Management with Cluster ID: 0x0062
4	Add Mounted On/Off Control as superset, add usage guidance for both device types

5.1.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x010A	On/Off Plug-in Unit		Simple	Endpoint

5.1.3. Conditions

See the Base Device Type definition for conformance tags.

5.1.4. Cluster Requirements

Each endpoint supporting this device type SHALL include these clusters based on the conformance defined below.

Table 3. On/Off Plug-in Unit Cluster Requirements

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x0003	Identify	Server		M
0x0004	Groups	Server		M
0x0006	On/Off	Server		M
0x0008	Level Control	Server		O
0x0062	Scenes Management	Server		M
0x0406	Occupancy Sensing	Client		O

The inclusion of the Level Control cluster on this device is recommended to provide a consistent user experience when the device is grouped with additional dimmable lights and the “with on/off” commands are used. For this device, since its only states are on or off, if the Level Control cluster is implemented, it SHALL NOT have any effect on the actual light level except for those commands that cause an on/off state change, that is, the “with on/off” commands. In addition, if the Level Control cluster is implemented, the device SHALL accept and process Level Control cluster commands, adjusting the value of the CurrentLevel attribute accordingly and, where necessary, adjusting the On/Off cluster OnOff attribute.