

This device type is intended for any wall-mounted or hardwired load controller, while [Section 5.1, “On/Off Plug-in Unit”](#) is intended only for smart plugs and other power switching devices that are not permanently connected, and which can be unplugged from their power source.

NOTE

Since this device type was added in Matter 1.4, for endpoints using this device type it is RECOMMENDED to add the subset device type [Section 5.1, “On/Off Plug-in Unit”](#) to the DeviceTypeList of the Descriptor cluster on the same endpoint for backward compatibility with existing clients.

See [\[ref_MountedOnOffClientGuidance\]](#) for client guidance with these two device types.

5.3.1. Revision History

Revision	Description
1	Initial release
2	Add superset classification and usage guidance for both device types

5.3.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x010F	Mounted On/Off Control	On/Off Plug-in Unit	Simple	Endpoint

5.3.3. Conditions

See the Base Device Type definition for conformance tags.

5.3.4. Cluster Requirements

Each endpoint supporting this device type SHALL include these clusters based on the conformance defined below.

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x0003	Identify	Server		M
0x0004	Groups	Server		M
0x0006	On/Off	Server		M
0x0008	Level Control	Server		O
0x0062	Scenes Management	Server		M
0x0406	Occupancy Sensing	Client		O