

multiscreen.org/).

The Application Launcher cluster SHALL be used for this functionality.

10.1.7.2. Launch Content from another Device

Content search and launch is defined by the Content Launcher cluster which includes feature flags for Content Search and URL Playback which are used to indicate which of these features is supported.

The Content Launcher cluster SHALL be used for this functionality.

10.2. Basic Video Player Device Type

This defines conformance to the Basic Video Player device type.

A Video Player (either Basic or Casting) represents a device that is able to play media to a physical output or to a display screen which is part of the device.

A Basic Video Player has playback controls (play, pause, etc.) and keypad remote controls (up, down, number input), but is not able to launch content and is not a content app platform (the Casting Video Player device type is used for these functions).

For example, a Basic Video Player can be a traditional TV device a physical media playback device such as a DVD Player, or a device that provides input to another device like a TV or computer monitor.

See [Section 10.1, “Video Player Architecture”](#) for additional Basic Video Player requirements relating to Video Player device endpoint composition, commissioning, feature representation in clusters, and UI context.

10.2.1. Revision History

Revision	Description
1	Initial revision
2	Added Messages and Content Control clusters

10.2.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x0028	Basic Video Player		Simple	Endpoint

10.2.3. Conditions

This device type SHALL support the following conformance conditions as defined below.