

Chapter 16. Camera Device Types

16.1. Camera Device Type

A Camera device is a camera that provides interfaces for controlling and transporting captured media, such as Audio, Video or Snapshots.

16.1.1. Revision History

Revision	Description
1	Initial release

16.1.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x0142	Camera		Simple	Endpoint

16.1.3. Conditions

See the Base Device Type definition for conformance tags.

16.1.4. Device Type Requirements

A Camera MAY expose elements of its functionality through one or more additional device types on different endpoints. All devices used in compositions SHALL adhere to the disambiguation requirements of the System Model. Other device types, not explicitly listed in the table, MAY also be included in device compositions but are not considered part of the core functionality of the device.

Cameras which implement occupancy detection based on the signals from the optical sensor, MAY expose this functionality using an Occupancy Sensing cluster on the primary camera endpoint along with the other [camera functionality](#). The device type Occupancy Sensor SHALL NOT be added to the DeviceTypeList of this endpoint.

Cameras MAY have an Occupancy Sensor of a different type for occupancy detection independent of the optical sensor. If this sensor is exposed, it SHALL be placed on a child endpoint of the primary camera endpoint, with the corresponding device type Occupancy Sensor, as indicated in the following table:

Device Type ID	Device Type Name	Constraint	Conformance
0x0107	Occupancy Sensor		O

16.1.5. Condition Requirements

The table below lists conditions and conformance values that override the device type definition.