4.33. getLocationInfo

For retrieving Location information

Request Parameters

URI	<BaseURL>/v1/system/getLocationInfo
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/getLocationInfo

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details
id	string	Returns Location ID in 32-digit hex
name	string	Returns Location Name
zone_list	object	Returns Location setup status of each Zone. Retrievable only when each Zone is valid
|- main	boolean	Returns whether or not Main Zone Location setup is valid
|- zone2	boolean	Returns whether or not Zone2 Location setup is valid
|- zone3	boolean	Returns whether or not Zone3 Location setup is valid
|- zone4	boolean	Returns whether or not Zone4 Location setup is valid
stereo_pair_status	string	Returns Stereo Pair setting status Values : "none" / "master_left" / "master_right" / "slave_left" / "slave_right"

Example Response	{
	  "response_code":0,
	  "id":"9A237BF5AB80ED3C7251DFF49825CA42",
	  "name":"Home",
	  "zone_list":{
	    "main":true,
	    "zone2":true,
	    "zone3":false
	  },
	  "stereo_pair_status":"none"
	}

4.34. getStereoPairInfo

For retrieving Stereo Pair information

Request Parameters

URI	<BaseURL>/v1/system/getStereoPairInfo
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/getStereoPairInfo