Example Response	{
	
	  "response_code":0,
	
	  "device_status":"ready",
	
	  "playback":"play",
	
	  "repeat":"all",
	
	  "shuffle":"on",
	
	  "repeat_available":[
	
	      "off",
	
	      "one",
	
	      "all"
	
	      "folder"
	
	  ],
	
	  "shuffle_available":[
	
	      "off",
	
	      "on"
	
	      "folder"
	
	  ],
	
	  "play_time":100,
	
	  "total_time":300,
	
	  "track_number":5,
	
	  "total_tracks":13,
	
	  "artist":"Mr.Children",
	
	  "album":"SUPERMARKET FANTASY",
	
	  "track":"GIFT"
	
	}

8.2. setPlayback

For controlling playback status

Request Parameters

name	type	required	description
playback	string	yes	Specifies playback status Values: "play" / "stop" / "pause" / "previous" / "next" / "fast_reverse_start" / "fast_reverse_end" / "fast_forward_start" / "fast_forward_end" / "track_select "
num	integer	no	Specifies target track number to playback. This parameter is valid only when playback "track_select" is specified. Values: 1 ~ 512

URI	\<BaseURL\>/v1/cd/setPlayback?playback=\<playback\>&num=\<num\>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/cd/setPlayback?playback=stop

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details