

	<pre> "alarm_on":true, "volume":40, "fade_interval":180, "fade_type":1, "mode":"oneday", "repeat":false, "oneday":{ "enable":true, "time":"0730", "beep":false, "playback_type":"preset", "preset":{ "type":"netusb", "num":8, "netusb_info":{ "input":"pandora", "text":"Queen Radio" } } }, ... "saturday":{ ... } } </pre>
--	---

9.2. setAutoSync

For setting clock time auto sync. Available only when "date_and_time" exists in clock - func_list under /system/getFeatures.

Request Parameters

name	type	required	description
enable	boolean	yes	Specifies whether or not clock auto sync is valid

URI	<BaseURL>/v1/clock/setAutoSync?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/clock/setAutoSync?enable=true

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre>{ "response_code":0 }</pre>
------------------	--------------------------------------