
5.1.	getStatus	48
5.2.	getSoundProgramList	50
5.3.	setPower	51
5.4.	setSleep	52
5.5.	setVolume	52
5.6.	setMute.....	53
5.7.	setInput	53
5.8.	setSoundProgram	54
5.9.	set3dSurround	54
5.10.	setDirect	55
5.11.	setPureDirect	55
5.12.	setEnhancer	56
5.13.	setToneControl	56
5.14.	setEqualizer	57
5.15.	setBalance	58
5.16.	setDialogueLevel	59
5.17.	setDialogueLift	59
5.18.	setClearVoice.....	60
5.19.	setSubwooferVolume	60
5.20.	setBassExtension.....	61
5.21.	getSignalInfo	61
5.22.	prepareInputChange	62
5.23.	recallScene	63
5.24.	setContentsDisplay.....	63
5.25.	controlCursor	64
5.26.	controlMenu	64
5.27.	setActualVolume	65
5.28.	setAudioSelect.....	65
5.29.	setSurroundDecoderType.....	66
6.	Tuner	67
6.1.	getPresetInfo.....	67
6.2.	getPlayInfo	68
6.3.	setBand.....	70
6.4.	setFreq.....	71
6.5.	recallPreset	72
6.6.	switchPreset.....	72
6.7.	storePreset	73
6.8.	clearPreset.....	73
6.9.	startAutoPreset.....	74
6.10.	cancelAutoPreset	74
6.11.	movePreset.....	75
6.12.	startDabInitialScan	75
6.13.	cancelDabInitialScan	76
6.14.	setDabTuneAid	76
6.15.	setDabService	77
7.	Network/USB	78
7.1.	getPresetInfo.....	78
7.2.	getPlayInfo	79
7.3.	setPlayback	82