		device list is being updated via /system/updateBluetoothDeviceList
device_list	array	Returns Bluetooth device list
|-- name	string	Returns device name (max size is 128 bytes).
|-- type	string	Returns type of device. Values: "loudspeaker" / "headphone" / "handsfree_device" / "unknown"
|- address	string	Returns BT address (12-digit hex)

Example Response	```{```
	 ``` "response_code":0,```
	 ``` "updating":false,```
	 ``` "device_list":[```
	 ``` {```
	 ``` "name":"Yamaha Speaker",```
	 ``` "type":"loudspeaker",```
	 ``` "address":"9AF2B8CE1580"```
	 ``` },```
	 ``` ...```
	 ``` {```
	 ``` "name":"Yamaha Headphone",```
	 ``` "type":"headphone",```
	 ``` "address":"C259197BD6F5"```
	 ``` }```
	 ```]```
	 ```}```

4.18. updateBluetoothDeviceList

For updating Bluetooth (Sink) device list. This API is available only when "bluetooth_tx_setting" is true under /system/getFuncStatus.
Retrieve update status and list information after finish updating via /system/getBluetoothDeviceList.

Request Parameters

URI	<BaseURL>/v1/system/updateBluetoothDeviceList
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/updateBluetoothDeviceList

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details

Example Response	```{```
	 ``` "response_code":0```
	 ```}```