

	<p>b[3] Capable of Prev Skip b[4] Capable of Next Skip b[5] Capable of Fast Reverse b[6] Capable of Fast Forward b[7] Capable of Repeat b[8] Capable of Shuffle b[9] Feedback Available (Pandora) b[10] Thumbs-Up (Pandora) b[11] Thumbs-Down (Pandora) b[12] Video (USB) b[13] Capable of Bookmark/Favorite (Net Radio / TIDAL / Deezer) b[14] DMR Playback (Server) b[15] Station Playback (Napster) b[16] AD Playback (Pandora) b[17] Shared Station (Pandora) b[18] Capable of Add Track (Napster/Pandora/JUKE/Qobuz) b[19] Capable of Add Album (Napster / JUKE) b[20] Shuffle Station (Pandora) b[21] Capable of Add Channel (Pandora) b[22] Sample Playback (JUKE) b[23] MusicPlay Playback (Server) b[24] Capable of Link Distribution b[25] Capable of Add Playlist (Qobuz) b[26] Capable of add MusicCast Playlist b[27] Capable of Add to Playlist (TIDAL / Deezer)</p> <p>With Pandora, b[9] = 1 validates "thumbs_up" / "thumbs_down" / "mark_tired" of managePlay and "why_this_song" of getPlayDescription. b[21] = 1 validates "add_channel_track" / "add_channel_artist"</p>
--	--

Example Response	<pre>{ "response_code":0, "input":"usb", "playback":"stop", "repeat":"off", "shuffle":"on", "repeat_available": ["off", "one"], "shuffle_available": ["off", "on"], "play_time":200, "total_time":314, "artist":"尾崎豊", "album":"壊れた扉から", }</pre>
------------------	--