

```
"alive":true,  
"ip_address":"192.168.0.11",  
"mac_address":"00A0DE012345"  
}  
}
```

Request

<http://{DeviceB}/YamahaExtendedControl/v1/system/getStereoPairInfo>

Response

```
{  
    "response_code":0,  
    "status":"slave_right",  
    "pair_info":{  
        "alive":true,  
        "ip_address":"192.168.0.10",  
        "mac_address":"00A0DE012346"  
    }  
}
```

Control master device. Slave device operate simultaneously with master device.

Request

<http://{DeviceA}/YamahaExtendedControl/v1/main/setPower?power=standby>

Response

```
{  
    "response_code":0,
```



13.5. Polling

Polling interval of special application "MusicCast CONTROLLER".(reference information)

1. Always every 10 seconds for all rooms.
2. Always every 5 seconds for the selected MusicCast device.
(Since information can be acquired by events, please adjust the polling interval to an appropriate value depending on the system to be used.)

Polling is necessary for "get command" which may be updated in real time.

1. For all MusicCast devices being detected

[getLocationInfo](#)

2. For MusicCast devices of the same location only

[getDistributionInfo](#) (Please refer to YXC_API_Spec_Advanced.pdf)

3. For each room at the same location

[/\(zone\)/getStatus](#)

[/\(type\)/getPlayInfo](#) (Please use properly according to the current input, eg net/usb, tuner, cd...)