

4.42. setPartyMode

For setting Party Mode. Available only when " party_mode " exists in system - func_list under /system/getFeatures.

Request Parameters

Name	type	required	description
Enable	boolean	yes	Specifies Party Mode setting. Values : true (Enable), false (disable)

URI	<BaseURL>/v1/system/setPartyMode?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setPartyMode?enable=true

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------