

## 4.40. setAutoPlay

For setting Auto Play of device. Available only when " auto play function " exists in system - func\_list under /system/getFeatures.

### Request Parameters

name	type	Required	description
enable	boolean	Yes	Specifies Auto Play setting Values : true (enable) , false (disable)

URI	<BaseURL>/v1/system/setAutoPlay?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setAutoPlay?enable=true

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

## 4.41. setSpeakerPattern

For setting speaker of device. Available only when " speaker\_pattern function " exists in system - func\_list under /system/getFeatures.

### Request Parameters

name	type	required	description
num	integer	yes	Specifies Speaker pattern number. Values : 1~speaker_pattern number from /system/getFeatures

URI	<BaseURL>/v1/system/setSpeakerPattern?num=<num>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setSpeakerPattern?num=1

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------