

4.26. setDimmer

For setting FL/LED Dimmer

Request Parameters

name	type	required	description
value	integer	yes	Setting Dimmer. Specifies -1 in case of auto setting. Specifies 0 or more than 0 in case of manual setting. Auto setting is available only when -1 is exists in vale range under /system/getFeatures. Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures

URI	<BaseURL>/v1/system/setDimmer?value=<value>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setDimmer?value=3

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

4.27. setZoneBVolumeSync

For setting Zone B volume sync

Request Parameters

name	type	required	description
enable	boolean	yes	Specifies whether or not Zone B volume sync Zone A volume.

URI	<BaseURL>/v1/system/setZoneBVolumeSync?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setZoneBVolumeSync?enable=true

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------