

4.36. getRemoteInfo

For retrieving remote monitor information. Available only when "remote_info" exists in system - func_list under /system/getFeatures.

URI	<BaseURL>/v1/system/getRemoteInfo
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/getRemoteInfo

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details
model_name	string	Returns model name. Same value as /system/getDeviceInfo - model_name Ex : "RX-V479" / "HTR-4068" / ... / "WXC-50" / "UNKNOWN"
destination	string	Returns Device's destination region code. Same value as /system/getDeviceInfo - destination Values: "J" / "U" / "C" / "R" / "B" / "G" / "BG" / "T" / "A" / "L" / "K" / "E" / "V" / "F" / "P" / "S" / "H"
manufacture	string	"Yamaha Corporation"
system_version	floating point	Returns System Version . Same as /system/getDeviceInfo - system_version
api_version	floating point	Returns API Version. Same as /system/getDeviceInfo - api_version
netmodule_version	string	Returns Network Module version. Same as /system/getDeviceInfo - netmodule_version
netmodule_checksum	string	Return check-sum of Network Module in hex. Same value as /system/getDeviceInfo - netmodule_checksum
serial_number	string	Returns Serial Number(16 alphanumeric characters)
ip_address	string	Returns IP Address. Same value as /system/getNetworkStatus - ip_address
mac_address	object	Returns MAC Address (12 digit ASCII). Same value as /system/getNetworkStatus - mac_address
- wired_lan	string	Returns wired MAC Address
- wireless_lan	string	Returns wireless (Wi-Fi) MAC Address
- wireless_direct	string	Returns wireless (Wireless Direct) MAC Address
network_standby	string	Returns setup of Network Standby. Same value as /system/getNetworkStandby - network_standby Values : "off" / "on" / "auto"
main	object	Returns Main Zone related information
- power	string	Returns power status. Same value as /main/getStatus - power Value : "on" / "standby"
- input	string	Returns selected Input ID. Same value as /main/getStatus - input Values: Input IDs gotten via /system/getFeatures
zone2	object	Returns information related to Zone2. This data format is same as