

	<pre> "fm": { "preset": 0, "freq": 87500, "tuned": true }, "rds": { "program_type": "Affairs", "program_service": "RDS PS", "radio_text_a": "RDS Radio Text A", "radio_text_b": "RDS Radio Text B" }, "dab": { "preset": 10, "id": 10000, "status": "ready", "freq": 22564, "category": "primary", "audio_mode": "stereo", "bit_rate": 128, "quality": 90, "tune_aid": 80, "off_air": false, "dab_plus": false, "program_type": "Pop Music", "ch_label": "12D", "service_label": "BBC Radio 1", "dls": "The Chart Game: www.bbc.co.uk/radio2", "ensemble_label": "BBC Network DAB" }, "hd_radio": { "program": 1, "program_list": [1, 2, 3], "station": "WXYZ-FM", "category": "Top 40", "title": "Beat It", "artist": "Michael Jackson", "album": "Thriller" } } </pre>
--	--

6.3. setBand

For setting Tuner Band