input sources. Comfirm the result whether register to a preset or not via netusb | - preset_control (11.3 Details of event data).

Request Parameters

name	type	required	description
num	integer	yes	Specifying a preset number Value: one in the range gotten via /system/getFeatures

URI	<BaseURL>/v1/netusb/storePreset?num=<num>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/netusb/storePreset?num=10

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details

Example Response	{
	   "response_code":0
	}

7.14. clearPreset

For clearing Preset

Request Parameters

name	type	required	description
num	integer	yes	Specifies Preset number Values: one in the range gotten via /system/getFeatures

URI	<BaseURL>/v1/netusb/clearPreset?num=<num>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/netusb/clearPreset?num=10

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details

Example Response	{
	   "response_code":0
	}

7.15. movePreset

For moving preset.
For example, if excute movePreset?from=4&to=2 for list {[A], [B], [C], [D], [E] ...}, list is arranged as {[A], [D], [B], [C], [E] ...}.