



INSTALLATION MANUAL

AIR CONDITIONER

Please read this installation manual completely before installing the product.
Installation work must be performed in accordance with the national wiring
standards by authorized personnel only.

Please retain this installation manual for future reference after reading it
thoroughly.

Cable Assembly
PZCWRCG3



P/NO : 3828A20860M



www.lg.com

TABLE OF CONTENTS

■ Part Description	3
■ Installation Guide	4
■ Wiring diagram to use Group control.....	4
■ Installing step	4

Part Description

This Accessory is used to help Wired Remote group control




1 Cable assembly for indoor units: 1EA

2 Cable assembly for Connecting indoor to indoor: 1EA

Installation Guide

Wiring diagram to use Group control




Installing step

Please Connect wire **1** , **2**

For detail installation method Please refer to below wiring diagram.

Note :

- 1** Cable assembly for indoor units
- 2** Cable assembly for Connecting indoor to indoor
 - Please connect cable assembly **1** with already connected indoor unit





Ver.1.0.0