

### 8.14.7.3 SUBSCRIBE START

Address offset: 0x080

## Subscribe configuration for task START

#### 8.14.7.4 SUBSCRIBE STOP

Address offset: 0x084

## Subscribe configuration for task STOP

## 8.14.7.5 EVENTS STARTED

Address offset: 0x100

PDM transfer has started

#### 8.14.7.6 EVENTS STOPPED

Address offset: 0x104

PDM transfer has finished