

8.25.13.24 INTEN

Address offset: 0x300

Enable or disable interrupt

Bit number			31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																	
ID			R	Q	P	O	N	M	L	K	J	I	H	G	F	E	D	C	B	A
Reset 0x00000000			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID																Description	
A	RW	CTS	Enable or disable interrupt for event CTS																	
			Disabled																Disable	
			Enabled																Enable	
B	RW	NCTS	Enable or disable interrupt for event NCTS																	
			Disabled																Disable	
			Enabled																Enable	
C	RW	TXDRDY	Enable or disable interrupt for event TXDRDY																	
			Disabled																Disable	
			Enabled																Enable	
D	RW	RXDRDY	Enable or disable interrupt for event RXDRDY																	
			Disabled																Disable	
			Enabled																Enable	
E	RW	ERROR	Enable or disable interrupt for event ERROR																	
			Disabled																Disable	
			Enabled																Enable	
F	RW	RXTO	Enable or disable interrupt for event RXTO																	
			Disabled																Disable	
			Enabled																Enable	
G	RW	TXSTOPPED	Enable or disable interrupt for event TXSTOPPED																	
			Disabled																Disable	
			Enabled																Enable	
H	RW	DMARXEND	Enable or disable interrupt for event DMARXEND																	
			Disabled																Disable	
			Enabled																Enable	
I	RW	DMARXREADY	Enable or disable interrupt for event DMARXREADY																	
			Disabled																Disable	
			Enabled																Enable	
J	RW	DMARXBUSERRO	Enable or disable interrupt for event DMARXBUSERRO																	
			When this event is generated, the address which caused the error can be read from the BUSERRORADDRESS register.																	
			Disabled																Disable	
K-N	RW	DMARXMATCH[i] (i=0..3)	Enable or disable interrupt for event DMARXMATCH[i]																	
			Disabled																Disable	
			Enabled																Enable	
O	RW	DMATXEND	Enable or disable interrupt for event DMATXEND																	
			Disabled																Disable	
			Enabled																Enable	