

Bit number			31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID			R	Q	P	O	N	M	L	K	J	I	H	G	F	E	D	C	B	A	A	A	A	A	A	A	A	A	A	A	A			
Reset 0x00400082			0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	1	0				
ID	R/W	Field	Value ID	Value	Description																													
			Yes	1	The authentication module is busy.																													
E	R	AUTHENTICATED			Authentication status.																													
			No	0	Authentication required before using the debug module.																													
			Yes	1	Authentication passed.																													
F	R	ANYHALTED			Any currently selected harts halted status.																													
			No	0	None of the currently selected harts halted.																													
			Yes	1	Any of the currently selected harts halted.																													
G	R	ALLHALTED			All currently selected harts halted status.																													
			No	0	Not all of the currently selected harts halted.																													
			Yes	1	All of the currently selected harts halted.																													
H	R	ANYRUNNING			Any currently selected harts running status.																													
			No	0	None of the currently selected harts running.																													
			Yes	1	Any of the currently selected harts running.																													
I	R	ALLRUNNING			All currently selected harts running status.																													
			No	0	Not all of the currently selected harts running.																													
			Yes	1	All of the currently selected harts running.																													
J	R	ANYUNAVAIL			Any currently selected harts unavailable status.																													
			No	0	None of the currently selected harts unavailable.																													
			Yes	1	Any of the currently selected harts unavailable.																													
K	R	ALLUNAVAIL			All currently selected harts unavailable status.																													
			No	0	Not all of the currently selected harts unavailable.																													
			Yes	1	All of the currently selected harts unavailable.																													
L	R	ANYNONEEXISTENT			Any currently selected harts nonexistent status.																													
			No	0	None of the currently selected harts nonexistent.																													
			Yes	1	Any of the currently selected harts nonexistent.																													
M	R	ALLNONEEXISTENT			All currently selected harts nonexistent status.																													
			No	0	Not all of the currently selected harts nonexistent.																													
			Yes	1	All of the currently selected harts nonexistent.																													
N	R	ANYRESUMEACK			Any currently selected harts acknowledged last resume request.																													
			No	0	None of the currently selected harts acknowledged last resume request.																													
			Yes	1	Any of the currently selected harts acknowledged last resume request.																													
O	R	ALLRESUMEACK			All currently selected harts acknowledged last resume.																													
			No	0	Not all of the currently selected harts acknowledged last resume.																													
			Yes	1	All of the currently selected harts acknowledged last resume.																													
P	R	ANYHAVERESET			Any currently selected harts have been reset and reset is not acknowledged.																													
			No	0	None of the currently selected harts have been reset and reset is not acknowledged.																													
			Yes	1	Any of the currently selected harts have been reset and reset is not acknowledged.																													
Q	R	ALLHAVERESET			All currently selected harts have been reset and reset is not acknowledged.																													
			No	0	Not all of the currently selected harts have been reset and reset is not acknowledged.																													