

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		G F E D C B A			
Reset 0x00000000		0 0			
ID	R/W	Field	Value ID	Value	Description
F	RW	XOTUNEERROR			Write '1' to enable interrupt for event XOTUNEERROR
		W1S			
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
G	RW	XOTUNEAFAILED			Write '1' to enable interrupt for event XOTUNEAFAILED
		W1S			
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled

5.4.3.26 INTENCLR

Address offset: 0x308

Disable interrupt

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		G F E D C B A			
Reset 0x00000000		0 0			
ID	R/W	Field	Value ID	Value	Description
A	RW	XOSTARTED			Write '1' to disable interrupt for event XOSTARTED
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
B	RW	PLLSTARTED			Write '1' to disable interrupt for event PLLSTARTED
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
C	RW	LFCLKSTARTED			Write '1' to disable interrupt for event LFCLKSTARTED
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
D	RW	DONE			Write '1' to disable interrupt for event DONE
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
E	RW	XOTUNED			Write '1' to disable interrupt for event XOTUNED
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
F	RW	XOTUNEERROR			Write '1' to disable interrupt for event XOTUNEERROR
		W1C			
			Clear	1	Disable
			Disabled	0	Read: Disabled