

Stop LFCLK source

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		A			
Reset 0x00000000	0 0				
ID	R/W	Field	Value ID	Value	Description
A	W	TASKS_LFCLKSTOP			Stop LFCLK source
		Trigger		1	Trigger task

5.4.3.7 TASKS_CAL

Address offset: 0x018

Start calibration of LFRC oscillator

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		A			
Reset 0x00000000	0 0				
ID	R/W	Field	Value ID	Value	Description
A	W	TASKS_CAL			Start calibration of LFRC oscillator
		Trigger		1	Trigger task

5.4.3.8 TASKS_XOTUNE

Address offset: 0x01C

Request tuning for HFXO

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		A			
Reset 0x00000000	0 0				
ID	R/W	Field	Value ID	Value	Description
A	W	TASKS_XOTUNE			Request tuning for HFXO
		Trigger		1	Trigger task

5.4.3.9 TASKS_XOTUNEABORT

Address offset: 0x020

Abort tuning for HFXO

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID		A			
Reset 0x00000000	0 0				
ID	R/W	Field	Value ID	Value	Description
A	W	TASKS_XOTUNEABORT			Abort tuning for HFXO
		Trigger		1	Trigger task

5.4.3.10 SUBSCRIBE_XOSTART

Address offset: 0x080

Subscribe configuration for task XOSTART